

Correct. You need a newer camera (C3, C5, C14plus) or an earlier version of the software.

You will find the earlier version software, Capture V1.8 for ProgRes C10 / C12 / C14 at the following link:

<http://eyelike.jenoptik-los-it.de>

Username: nobody

Password: nobody

To unzip the downloaded with the password: progres