



## Press Release

Page: 1 von 3  
Date: 26.09.2011

# Jenoptik presents innovative industrial LED Hall Lighting at the trade fair efa

The Jenoptik Business Unit Optoelectronic Systems displays the hall and high rack luminaire Lucid power high bay at the efa, trade fair for building systems, electrical engineering, air conditioning and automation in Leipzig.

In cooperation with LEIDS GmbH & Co. KG, the Lucid power high bay is the first of a new series of LED hall luminaire for the use in high halls and buildings. This new series of luminaires is Jenoptik's response to the greater demand by commercial customers for cost efficient and low-maintenance LED lighting

The new hall and high rack luminaire ensures an efficiency of more than 100 lumen/watt with a life time of up to 60.000 h, low heat development and low energy consumption, typical for LED luminaires. The optimized 3-chip-LEDs combined with the highly efficient lens array achieves a homogeneous illumination without scattering losses, and an increase in brightness by a factor of 2 while consuming the same energy as conventional luminaires. The enormous efficiency of this new series of LED luminaires promises a project dependant short amortization period of less than three years. This luminaire is suitable for new installations as well as for conversion/replacement projects.

The Lucid power high bay offers two variations based on the application requirements. The first luminaire with a radiation angle of 60° and a circular light pattern is especially suitable for industrial and sports halls, as well as for warehouses. The second type transmits an elliptical light pattern with a radiation angle of 30/60° and is therefore predestined for illumination of logistic halls and storage buildings with corridors. Customers can choose between four different color temperatures: cold-white, daylight-white, normal-white and warm-white.

The polycarbonate cover plate of the Lucid power high bay is impact-resistant and shatter-proof. The luminaire is cold resistant down to ca. -25° and is protected from overheating in warm environments with the aluminium heat sink. Both luminaire solutions meet the IP66 protection class.





## Press Release

Page: 2 von 3  
Date: 26.09.2011

Visit us at the trade fair efa in Leipzig from the 12<sup>th</sup> to the 14<sup>th</sup> October 2011 at our booth E38 in hall 5.  
Our team looks forward to your visit!



Picture  
Lucid power high bay

## About the Jenoptik Business Unit Optoelectronic Systems

The Business Unit Optoelectronic Systems, as part of the Jenoptik Division Optical Systems, is provider of integrated opto-electronic system solutions. The business unit has competencies in development of optics, electronics and software, and owns manufacturing technologies for producing polymer-based optical and electronic components and modules as well as assembly technologies for complete devices. The Business Unit Optoelectronic Systems can realize all important stages of the value-added chain for system integration – from development and design to prototype production through supply chain management and series production.

With its Optical Systems division, the Jenoptik Group is one of the few manufacturers in the world to produce precision optics and systems designed to meet the highest quality standards. Besides systems, modules and assemblies, the Optical Systems division is a development and production partner for optical, microoptical and coated optical components - made of optical glasses, IR materials as well as polymers. It possesses outstanding expertise in the development and manufacture of optics and microoptics for beam shaping used in the semiconductor industry and laser material processing.

The product portfolio also includes systems and components for life sciences as well as lighting applications, modules and system solutions for digital image capture and processing as well as cameras for digital microscopy.

## Press Release



Page: 3 von 3  
Date: 26.09.2011

### About the LEIDS GmbH & Co. KG:

LEIDS GmbH & Co. KG is a subsidiary of the Taiwanese LED manufacturer ALDER Optomechanical Corp., founded in 2002. Since the middle of 2008 the company designs and markets complete lighting solutions with the trade mark LEIDS in whole Europe. The LEIDS GmbH & Co. KG, as the operational European subsidiary, is responsible for development and certification of luminaires as well as for distribution and sales management of the trade mark LEIDS.

By now, the LEIDS GmbH & Co. KG has branches in Switzerland, in Greece, in the Benelux countries and Poland as well as in Turkey and Qatar. LEIDS can react flexibly and quickly to changing market requirements and offers LED solutions with state-of-the-art technologies because of its expertises in LED development and production. The relaunch "LEIDS - switch it on" in May 2011 was the next big milestone for positioning the brand LEIDS in the European market.

### Contact

Mathias Goebel  
Key Account Manager Lighting

JENOPTIK | Optical Systems  
JENOPTIK Polymer Systems GmbH  
Am Sandberg 2 | 07819 Triptis | Germany  
Tel.: +49 36482 45-128 | Fax -45-226  
lighting-oes.os@jenoptik.com  
www.jenoptik.com/oes\_lighting